PRISM

USER MANUAL

Overview

DC OUT

OUTPUT
DC5~24V 6A

INPUT
DC5~24V

DC IN

Keys instruction

① **Timer on with 8 hours daylight** ② **Timer off.**

① **Increase 1 hour** ② **Increase 20% intensity.**

① **Decrease 1 hour** ② **Decrease 20% intensity.**

① **ON/OFF: Power ON/OFF** ② **Channels Selection, All RGB, Red, Green, Blue.**

Default 8 hours - 24 hours sycle show
(Start from 8:00 AM)

Timer setting

Press ② to start 8 hours daylight, 24 hours sycle. **(Waiting 8 seconds to Turn ON after PRESS or HOUR Adjust)**

Press ② then press ☼ ☀ to increase or decrease hour, 4 hours for max increase and mini decrease to adjust.

e.g. Current time is 8:00 am, set run 8 hours, the light will running 8 hours until 4:00 pm, then turn off automatic. Program will start from 8:00am automatic at everyday.

Intensity setting

Press ⏻ to select the all RGB channel, press again select Blue, press again select Red, press again select Green.

Press ☼ ☀ to adjust the intensity for each channels or all channels, the intensity will be save after adjust at each time.

Hold on ⏻ 5 second to turn off all the channels, press ⏻ to turn on.

Notes: The timer will not be saved once the electric cut off, lighting will turn on directly when the electric recover.